



Remarks

- 1 Rupture disk
- 2 Field supply
- 3 Discharge pipe
- 4 Support
- 5 Tank (Above 1 m<sup>3</sup> (35 cubic feet))
- 6 Vent pipe
- 7 Drain

Notes)

- 1) The rupture disk is factory-mounted on the chiller(/heater).
- 2) Install a receiver tank for the solution.  
The tank volume is approx. 1 cubic meter (35 cubic feet).
- 3) Install piping support near rupture disk connection.

**Carrier**  
**SANYO**

**Rupture disk  
connection**

Model

**All model**

Drawing code

**CM-018-001-00-1**