



No.	Parts name.	No.	Parts name.
1	Pump, without solenoid valve		
2	Solenoid valve		
4	Nozzle head		
5	Solenoid valve		
6	Pressure switch		
7	Oil regulator		
9	Filter		

Combustion
Diagram



Oil fired

TSA-16DJ-51 -- 82

DJ-009-012-00