



Flue connection

Insert the flue of field into the flue of the chiller/heater.
 The flue of the chiller/heater has stopper.
 The flue of field will stop at 100mm (4 inch) depth.

Inside flue diameter "D"

DJ-	mm	inch
11	250	9-7/8
12	250	9-7/8
13	250	9-7/8
14	250	9-7/8
21	350	13-3/4
22	350	13-3/4
23	350	13-3/4
24	350	13-3/4

DJ-	mm	inch
31	400	15-3/4
32	400	15-3/4
41	400	15-3/4
42	400	15-3/4
51	500	19-5/8
52	500	19-5/8
53	500	19-5/8

DJ-	mm	inch
61	600	23-5/8
62	600	23-5/8
63	600	23-5/8
71	700	27-1/2
72	700	27-1/2
73	700	27-1/2
81	700	27-1/2
82	700	27-1/2



Flue connection

Model

TSA-16DJ

Drawing code

DJ-025-002-00-0