



Note)

- a) Foundation bolt washers are shipped with chiller(/heater).
- b) Please prepare foundation bolts, nuts and washers at field.
Please choose material of foundation bolt and nut to SUS(Stainless steel).

Foundation bolt length

The length of foundation bolt is longer than total thickness of the parts 1, 2, 4 and 5.

In case of using rubber vibration isolator, bolt length is longer than total thickness of 1, 2, 3, 4, 5, 6 and 7.

Rubber Vibration Isolator (Optional parts)

- 1) Put on the mat base on the foundation.
- 2) Put on the mat on the mat base.
- 3) Set the chiller(/heater) on the mat.
- 4) Insert the washer to the foundation bolt.
- 5) Insert the mat washer to the foundation bolt.
- 6) Insert the washer (field supply) to the foundation bolt.
- 7) Fix the chiller(/heater) by double nuts.



**Foundation bolt length &
Rubber Vibration Isolator**

Model

All model

Drawing code

CM-012-001-00-2